


# SL 19

## Spare Parts Photo Book



Staying Home Corporation



## Table of Contents


<b>54018</b>	- Charger, Smart 24VDC . . . . .	3
<b>54015</b>	- PCB, AMI Main Control Board . . . . .	3
<b>54005</b>	- Switch, Plunger, 1DM1 . . . . .	3
<b>58012</b>	- Assy, Limit Cam . . . . .	3
<b>54011</b>	- Battery, 12V 5AH . . . . .	3
<b>74034</b>	- RF TX Fob, 2 Button, Gen 2. . . . .	3
<b>74033</b>	- RF Remote Receiver, Gen 2 . . . . .	3
<b>54013</b>	- Switch, Rocker. . . . .	3
<b>56005</b>	- Strip, Charge Finger (SL14) . . . . .	4
<b>56006</b>	- Strip, Charge Contact (SL14) . . . . .	4
<b>56035</b>	- Track Extrusion . . . . .	4
<b>56038</b>	- Slotted Gear Rack, 60" . . . . .	4
<b>58083</b>	- Assy, Track Splice Bar (2 per splice) . . . . .	4
<b>91040</b>	- Pin, Driv-Lok, 187x1.5 (1 per splice) . . . . .	4
<b>55016</b>	- Cover, Track Top. . . . .	4
<b>58079</b>	- Assy, Track End Cap SL19 . . . . .	4
<b>58064</b>	- Assy, Track Bracket . . . . .	5
<b>50029</b>	- 14x2.00-WL-HF-ZP (track bracket wood lags) . . . . .	5
<b>54051</b>	- Hrns, Travel Cable, 15' (prior to 3.1.21). . . . .	5
<b>58125</b>	- Assy-Sub, Charge Shoe . . . . .	5
<b>54023</b>	- Harness, Charger. . . . .	5
<b>58126</b>	- Assy-Sub, Charge Strip (must specify top or bottom). . . . .	5
<b>56036</b>	- Guide Block . . . . .	5
<b>50002</b>	- Washer, 3/4-1.25 x .07 FL-NY (guide block shims). . . . .	5
<b>94002</b>	- Switch, V7, No Actuator (overspeed switch, no arm) . . . . .	6
<b>94001</b>	- Switch, Sim Roll, V7-1B17D8-263 (seat swivel/final, has arm) . . . . .	6
<b>54031</b>	- LED, Diagnostic . . . . .	6
<b>54033</b>	- PCB, AMI Main Control Board, OUTDOOR . . . . .	6
<b>56033</b>	- Cover, Stairlift Outdoor Grey . . . . .	6
<b>54002</b>	- Circuit Breaker, 15A. . . . .	6
<b>58082</b>	- Sub, Motor/Pinion . . . . .	6
<b>59051</b>	- Cargo Tray . . . . .	6



54018 - Charger, Smart 24VDC



54015 - PCB, AMI Main Control Board



54005 - Switch, Plunger, 1DM1 (up/dn limit)




54011 - Battery, 12V 5AH



74033 - RF Remote Receiver, Gen 2



74034 - RF TX Fob, 2 Button, Gen 2




58012 - Assy, Limit Cam




54013 - Switch, Rocker



56005 - Strip, Charge Finger (SL14)



56006 - Strip, Charge Contact (SL14)



56035 - Track Extrusion (sold per foot)




56038 - Slotted Gear Rack (60" section)




58083 - Assy, Track Splice Bar (2 per splice)




91040 - Pin, Driv-Lok, 187x1.5 (1 per splice)



55016 - Cover, Track Top




58079 - Assy, Track End Cap SL19




58064 - Assy, Track Bracket




50029 - 14x2.00-WL-HF-ZP (wood lags)



54051 - Hrns, Travel Cable, 15' (prior to 3.1.21)



58125 - Assy-Sub, Charge Shoe



54023 - Harness, Charger




58126 - Charge Strip (specify top/bottom)




56036 - Guide Block




50002 - Guide Block Shims




94002 - Switch, No Actuator (overspeed)



94001 - Switch, Sim Roll (seat swivel, final)




54031 - LED, Diagnostic



54033 - PCB, Control Board (Outdoor)



56033 - Cover, Stairlift Outdoor Grey



54002 - Circuit Breaker, 15A



58082 - Sub, Motor/Pinion



59051 - Cargo Tray